

# Wonder Gun

## Jumbo Type

J-38

J-50

J-75

### 1. Connection with Compressor

Please connect air hose between the compressor and the hose joint of gun.  
Do not use easy joint such as the coupler since it may cause inefficient performance.  
Please use the designated hoses to each model to maintain optimal performance: 1/2+for J-38 and J-50, 3/4+for J-75.

### 2. Suction

For suction operation, attaching a short hose is preferred.  
Induce the air main air jet and compressed air simultaneously during suction operation.  
Depending on the transfer distance, please connect the guns in a row of 2 or 3 to maintain optimum performance.  
In case of 2 gun connection, combination with regular type and powerful type is available.  
Please inquire for the combination.

### 3. Discharge

Please open and close air cock SLOWLY during the discharge operation to avoid any risks of sudden and strong shock as a reaction.

Please confirm with the specifications tables to connect the air hoses for best performance.  
In case of insufficient compressed air supply, operation may result in low performance.



#### **DANGER**

**Please do a thorough read prior to the operation.**

- Please attach the dust collection bag during suction to prevent the sucked in materials from hitting a person or subjects, or it may cause serious damage to human body / life.
- Please be careful with the scattered materials when blowing.  
Please wear protection glasses while operating to prevent loss of eyesight, or the scattered materials may hit your eyes.
- Do not use this device on a human body.
- Do not suck anything considered as dangerous in general situation.
- Do not misuse as it might cause serious damage to human body / life.

#### **CAUTION**

- Please check if all the parts are tightened properly prior to each operation.
- Please make sure that no foreign substance is caught in the moving part, or the device may not operate properly.
- Please make sure the air hose is attached properly and fastened by the hose clamp at the Air Joint.  
If not, compressed air hose may disconnect and might become dangerous.
- Use with the air pressure gauge under 0.9MPa (9kg/cm<sup>2</sup>).
- Do not use beside ears.  
It may cause hearing disorder because of the exhaust noise.
- In case of using this device for adsorption, please test well whether the device adsorbs well since this is not designed for that purpose.
- This device is not suitable for liquid suction since it may lead to mist getting mixed with the air. The compressed air might get mixed with the sucked in materials when passing through this device during suction.  
Please use SILENT CLEANER for liquid suction.
- Do not use this device except for suction, blow off, or transfer.
- Use with the temperature under 40°C.
- Keep out of reach from children.
- In case you have any question about the usage, stop operation immediately and inquire the manufacturer.

**\* Please keep this caution note at a place where operator can easily read at anytime.**



1-7-28, Yunagi, Minato-ku, Osaka 552-0004 Japan  
TEL: +81-6-6572-1207 FAX: +81-6-6572-1256  
URL: <http://www.osawa-company.co.jp>  
E-mail: [osawa@osawa-company.co.jp](mailto:osawa@osawa-company.co.jp)