

# Wonder Gun

## Dust Collector

W1-20SET·W1-20

W3-20SET·W3-20

## Dust Collector Super

PCS-1·PC-1

PCS-3·PC-3



Dust Collector & Dust Collector Super are not applicable for liquid suction since the device provides mist mixed with the air. Their filters may get clogged during liquid suction. Please use SILENT CLEANER for liquid and powder suction.

### DANGER

**Please do a thorough read prior to the operation.**

- Please attach the dust collection bag during suction to prevent the sucked in materials from hitting a person or subjects, or it may cause serious damage to human body / life.
- Please be careful with the scattered materials when blowing. Please wear protection glasses while operating to prevent loss of eyesight, or the scattered materials may hit your eyes.
- Do not use this device on a human body.
- Do not suck anything considered as dangerous in general situation.
- Do not use it improperly; otherwise it will impair the human body, even causing death.
- Please be careful when handling the products. Do not drop them on the human body nor do on the floor; otherwise it can cause serious damages.

### CAUTION

- Please check if all the parts are tightened properly prior to each operation.
- Please make sure that no foreign substance is caught in the moving part, or the device may not operate properly.
- Please push the seal tape LIGHTLY into the hose joint while attaching the nipple to avoid breaking the service screw. The air hose joint is designed for tapered screw to attach air hose.
- Use with the air pressure gauge under 0.9MPa (9kg/cm<sup>2</sup>).
- Do not use beside ears. It may cause hearing disorder because of the exhaust noise.
- In case of using this device for adsorption, please test well whether the device adsorbs well since this is not designed for that purpose.
- This device is not suitable for liquid suction since it may lead to mist getting mixed with the air. The compressed air might get mixed with the sucked in materials when passing through this device during suction. Please use SILENT CLEANER for liquid suction.
- Do not use this device except for suction, blow off, or transfer.
- Use with the temperature under 40°C.
- Keep out of reach from children.
- In case you have question about the usage, stop operation immediately and inquire the manufacturer.

**\* Please keep this caution note at a place where operator can easily read at anytime**



**OSAWA & COMPANY**

1-7-28, Yunagi, Minato-ku, Osaka 552-0004 Japan  
TEL: +81-6-6572-1207 FAX: +81-6-6572-1256  
URL: <http://www.osawa-company.co.jp>  
E-mail: [osawa@osawa-company.co.jp](mailto:osawa@osawa-company.co.jp)